

Stop squeaky floors before they start

No-Squeak is a hybrid adhesive specifically designed to be used with our range of chipboard flooring. It is used to provide a sound absorbing and waterproof seal between flooring boards. The high quality hybrid adhesive has a strong and flexible bond, allowing for movement of flooring elements, helping to ensure long life, squeak free joints.



- Allows for structural movement without fracture or bond failure
- Excellent sound absorbing and noise reducing properties
- Does not expand or shrink and will not crack under stress
- Only 5 fixings (nails/screws) required per board rather than the usual 17 per board

Instructions for use:

- 1 Using a knife cut the nozzle at second graduated point.
- 2 Apply a 6mm bead of No-Squeak adhesive to the top of the joist or i-joist, using a skeleton gun. Use No-Squeak adhesive on joists and noggins in the area that is about to be directly laid.
- 3 For 22mm chipboard at 600mm centres only use 5 fixings (screws/nails) per 2400mm panel.
- 4 Continue to lay the Tongue & Groove panels in a staggered pattern.
- 5 Use Caberfix T&G PVA wood-working adhesive on the Tongue & Groove of the boards. No-Squeak can also be used to glue the Tongue & Groove.
- 6 No-Squeak will start to stick straight away but a full adhesive cure takes 24 hours.

Recommended usage guide: 1 tube to 3 boards when gluing both the T&G and boards to joists. 1 tube to 5 boards when only gluing boards to joists.

For use with P5 and solid wood flooring

www.no-squeak.co.uk